JacFab

"No drill" Front License Plate Bracket (GFX)

Installation instructions & disclaimer

•*Installation*

-Tools needed

-10mm Socket w/ short extension
-Ratchet
-5/32 Hex head wrench
-An assistant is helpful

Use the 10mm socket and ratchet to remove the 2 10mm bolts under the bumper cover (red arrows). Place the serrated lock washer on the supplied 10mm head bolts (black) first, followed by the normal washer (black), then insert the bolts through the bottom of the bracket. Next place the supplied spacer onto the bolt, on top of the bracket (pic below left). Hold the license plate bracket in place, inserting the bolt/spacer assembly through the hole on the bottom of the GFX (pic below right).

Begin to thread the bolts by hand. Be careful not to cross thread the bolts into their prospective mounting holes. Occasionally it can be difficult to get the bolt threads started, as you cannot see where they are going during this process. If it feels like the bolts are going in tight, or crooked, STOP, unscrew them, and try again. It may take a few tries to get the bolts started, as visibility is obstructed by the GFX. Once the bolts are started, use the ratchet and 10mm socket to tighten the bolts, do not tighten them all the way yet.

The mounting holes for the bottom of the bracket are slotted for adjustability, look down the front of the car to ensure the bracket is centered on the front of the car.

Not Centered

Centered

Pull one side of the bracket forward, or push one side backward to slide the bracket so that it's centered. Also ensure that the bracket isn't too far back. We recommend at least ½" inch of clearance between the bracket and the body of the car at the bottom. The brackets are slotted to fit a variety of different ground effects, hence the large amount of adjustability. Once you are happy with the alignment of the bracket to the car, and are comfortable with the distance of the bracket from the car, finish tightening the mounting bolts under the bumper with the ratchet and 10mm socket.

NOTE: *Blue loc-tite can be used on these mounting bolts if desired by the end user. DO NOT use red loc-tite!*

Slightly bend the license plate in the center and use the 5/32 hex head wrench to attach it using the supplied hex head screws with washers (silver hardware) to the four (4) holes in the face of the bracket.

Disclaimer: *You are installing this piece at your own risk. JacFab LLC. Or its associates cannot be held liable for any damages to the vehicle, any other property, personal injury, or injury to any other person caused by/from the installation of this piece on the end users vehicle.*

Bracket installed